



# DUALCOM PRO 2 RANGE

## INTRODUCTION


# DualCom Pro 2 Range

## Introduction

The DualCom Pro 2 Range offers Installers easier, faster installation of a professional signalling system with even greater resilience, plus access to CSL Live, our ordering and management portal.

Using the onboard serial connections, pins triggering or dial capture, DualCom Pro 2 is compatible with a wide range of control equipment including systems installed to EN50136 & PD6662. The range consists of DigiAir Pro 2 - our single-path solution that utilises a Radio path or LAN to signal an alarm; and GradeShift Pro 2 - our dual-path solution that utilises a combination of two Radio paths or one Radio and one LAN path to signal an alarm.

Figure 1 - DualCom Pro 2



**It's as Easy as 1, 2, 3!**

**Most DualCom Pro 2 units are ready to go after these few simple steps**



1) Wire and connect power - Refer to step 3 in the main quick guide for information on pins and serial connections



2) Wait 5 Minutes for LEDs 1-3 to go Green - Whilst your DualCom Pro 2 downloads its configuration



3) You're good to go! - For customisation use the CSL My Base App/Web Portal. For panel configuration instructions see our online guides

**Need a My Base Account?**

[CLICK HERE TO REGISTER](#)

**Need One Time My Base Access?**

[CLICK HERE](#)

**Need Panel Configuration Instructions?**

[CLICK HERE TO FIND YOUR PANEL](#)

**Need UDL Configuration & Install Instructions?**

[CLICK HERE TO FIND YOUR UDL GUIDE](#)